

## Palonniers - Ecarteurs MODULIFT



### Tableaux de charges CMOD MODULIFT

CMOD 06 / Charge Maximale en Tonne /  $\beta$  Maxi 30°

2,5	CMOD 06				8
2				8	8
1,5			8	8	8
1		8	8	8	6
0,5	8	8	8	6	6
Coté en mètre	0,5	1	1,5	2	2,5

CMOD 06 / Charge Maximale en Tonne /  $\beta$  Maxi 45°

2,5	CMOD 06				6
2				6	6
1,5			6	6	6
1		6	6	6	4
0,5	6	6	6	4	4
Coté en mètre	0,5	1	1,5	2	2,5

CMOD 12 / Charge Maximale en Tonne /  $\beta$  Maxi 30°

4	CMOD 12							16
3,5						16	16	
3					16	16	15	
2,5				16	16	15	14	
2			16	16	16	14	13	
1,5		16	16	16	16	14	12	
1		16	16	16	16	14	12	
0,5	16	16	16	16	16	14	12	
Coté en mètre	0,5	1	1,5	2	2,5	3	3,5	4

CMOD 12 / Charge Maximale en Tonne /  $\beta$  Maxi 45°

4	CMOD 12							9
3,5						9	9	
3					9	9	8	
2,5				9	9	8	8	
2			9	9	9	8	7	
1,5		9	9	9	9	8	6	
1		9	9	9	9	8	6	
0,5	9	9	9	9	9	8	6	
Coté en mètre	0,5	1	1,5	2	2,5	3	3,5	4

CMOD 24 / Charge Maximale en Tonne /  $\beta$  Maxi 30°

6	CMOD 24					23
5					30	21
4				30	24	19
3			30	30	24	18
2		30	30	30	24	17
1	30	30	30	24	22	16
Coté en mètre	1	2	3	4	5	6

CMOD 24 / Charge Maximale en Tonne /  $\beta$  Maxi 45°

6	CMOD 24					13
5					17	12
4				19	13	10
3			19	19	13	10
2		19	19	17	13	9
1	19	19	19	13	12	9
Coté en mètre	1	2	3	4	5	6

## Palonniers - Ecarteurs MODULIFT



### Tableaux de charges CMOD MODULIFT

CMOD 34 / Charge Maximale en Tonne /  $\beta$  Maxi 30°

8	CMOD 34							24
7						32	23	
6				40	31	22		
5			40	40	28	20		
4		40	40	34	26	19		
3		40	40	40	34	24	18	
2	40	40	40	40	32	23	17	
1	40	40	40	40	34	30	22	16
Coté en mètre	1	2	3	4	5	6	7	8

CMOD 34 / Charge Maximale en Tonne /  $\beta$  Maxi 45°

8	CMOD 34							13
7						18	13	
6				22	17	12		
5			27	22	16	11		
4		27	27	19	15	10		
3		27	27	25	19	13	10	
2	27	27	27	22	18	13	9	
1	27	27	27	27	19	17	12	9
Coté en mètre	1	2	3	4	5	6	7	8

CMOD 50 / Charge Maximale en Tonne /  $\beta$  Maxi 30°

11	CMOD 50										32
10								41	31		
9							50	39	29		
8						50	48	37	28		
7				60	50	45	35	27			
6			60	60	50	43	33	26			
5			60	60	60	50	40	32	25		
4		60	60	60	50	49	38	31	24		
3		60	60	60	60	50	47	37	30	23	
2	60	60	60	60	60	50	45	36	29	23	
1	60	60	60	60	60	60	50	44	35	28	22
Coté en mètre	1	2	3	4	5	6	7	8	9	10	11

CMOD 50 / Charge Maximale en Tonne /  $\beta$  Maxi 45°

11	CMOD 50										18
10								23	17		
9							28	21	16		
8						28	27	20	15		
7				34	28	25	19	14			
6			40	34	28	24	18	14			
5			40	40	34	28	23	17	13		
4		50	40	40	28	28	21	17	13		
3		50	50	40	40	28	26	21	16	12	
2	50	50	50	50	40	34	28	25	20	16	12
1	50	50	50	50	40	34	28	25	20	15	12
Coté en mètre	1	2	3	4	5	6	7	8	9	10	11

CMOD 70 / Charge Maximale en Tonne /  $\beta$  Maxi 30°

12	CMOD 70											63
11										70	60	
10								80	70	58		
9							80	80	70	55		
8						80	80	80	70	67	53	
7				80	80	80	80	70	65	51		
6			80	80	80	80	70	60	62	49		
5			80	80	80	80	80	70	60	60	47	
4		80	80	80	80	80	80	70	60	58	46	
3		80	80	80	80	80	80	70	60	56	45	
2	80	80	80	80	80	80	70	70	60	55	44	
1	80	80	80	80	80	80	80	70	70	60	54	44
Coté en mètre	1	2	3	4	5	6	7	8	9	10	11	12

CMOD 70 / Charge Maximale en Tonne /  $\beta$  Maxi 45°

12	CMOD 70											36
11										40	34	
10								40	40	33		
9							46	40	40	31		
8						57	46	40	38	30		
7				60	57	46	40	37	29			
6			60	60	57	40	34	35	28			
5			60	60	60	50	40	34	34	27		
4		60	60	60	60	50	40	34	33	26		
3		60	60	60	60	60	50	40	34	32	26	
2	60	60	60	60	60	60	50	40	34	31	25	
1	60	60	60	60	60	60	50	40	34	31	24	
Coté en mètre	1	2	3	4	5	6	7	8	9	10	11	12